

TK4SP Side Gantry Calibration

1. Dial Indicator



2. Panel for Balance



3. Cast iron level



4. Feeler gauge




1. Find the position ,and install the panel on the feet ,tighten 4 screws.



2. Loose all the screws



3. According to the rail direction ,to tighten the screw on the panel .



4. After adjustment the panel ,tighten all the screws on the feet .